

Side Window Deflectors
Quick and Easy Installation Instructions

CONTENTS

- (2) Venta-lators
- (1) instruction sheet
- (2) alcohol pads

IMPORTANT: Read all instructions carefully before beginning the installation. The Venta-lators mount on the **OUTSIDE** of the door frame. A trial fit is recommended. The ideal installation temperature is between 65°-110°F (18°-43°C).

STEP 1: Roll down the window. Clean the areas on the door frame where the Venta-lator will mount with an alcohol pad. Then wipe dry with a clean cloth. See **FIGURE 1**

STEP 2: To reduce the risk of tape contamination due to improper positioning, expose only 2" (5cm) of tape from each end of the flange. See **FIGURE 2**

STEP 3: Realign the Venta-lator with the precleaned locations on the door frame and check for proper placement. Do not proceed until Venta-lator is properly positioned. See **FIGURE 2**

STEP 4: With the Venta-lator in its final position, remove the remainder of the tape liner by pulling on the free ends. Press the entire flange to ensure proper adhesion of the taped to the door frame. See **FIGURE 3**

Repeat **STEPS 1-4** for opposite side deflector

NOTE: The passenger side Venta-lator has a notch in the flange to accommodate the factory installed side mirror. The foam tape should fit up snugly against the bottom of the mirror bracket. See **FIGURE 4**

Venta-lators available for:
Mack, Peterbilt, Kenworth, Freightliner,
International, Volvo and other manufacturers.

